



1 min



x1




x1




A x1



Bx1



- Lamp Switch. Short press - switch to turn on. Extended press - switch to turn of. 3 step dimmable, press switch to adjust.
- Interruptor. Presione brevemente el interruptor para encenderlo. Mantener presionado para apagar. Presione 3 veces para ajustar.
- Interrupteur. Appuyez brièvement sur le bouton pour allumer. Tenir pour fermer. Appuyez 3 fois pour le réglage.







JULIÀ GRUP Furniture Solutions S.L.

B-17616277

Pol. Ind. Bosc d'en Cuca

C / Tallers, 14

17410 Sils SPAIN

contact@kavehome.com