




E I C H H O L T Z

108182 CONSOLE TABLE SERENITY

ASSEMBLY INSTRUCTION


PARTS




4x




1x



1x



1



2

