








FELIX




DECORMET




FELIX




NO	NAME	PIECE	NO	İSİM	ADET
12	DRESSER RIGHT LEG	1 PC	12	ŞİFONYER SAĞ AYAK	1 AD
13	DRESSER LEFT LEG	1 PC	13	ŞİFONYER SOL AYAK	1 AD
14	DRESSER BACKREST	1 PC	14	ŞİFONYER ARKALIK	1 AD
15	DRESSER TOP TABLE	1 PC	15	ŞİFONYER ÜST TABLA	1 AD
16	MIRROR TABLE	1 PC	16	AYNA PANOSU	1 AD
17	MIRROR BOTTOM PART	2 PCS	17	AYNA PANO DESTEK	2 AD
18	DRESSER DRAWER LEFT SIDE PART	1 PC	18	ŞİFONYER ÇKM. SOL YAN	1 AD
19	DRESSER DRAWER RIGHT SIDE PART	1 PC	19	ŞİFONYER ÇKM. SAĞ YAN	1 AD
20	DRESSER DRAWER BACK PART	1 PC	20	ŞİFONYER ÇKM. ARKA	1 AD
21	DRESSER DRAWER BOTTOM PART	1 PC	21	ŞİFONYER ÇKM. DİP	1 AD
22	DRESSER DRAWER COVER PART	1 PC	22	ŞİFONYER ÇKM. KAPAK	1 AD



18




19



FELIX					
NO	NAME	PIECE	NO	İSİM	ADET
1			1		
2			2		
3			3		
4			4		
5			5		
6			6		
7			7		
8			8		
9			9		
10			10		
21			11		
23	FOOTSTOOL RIGHT-LEFT SIDE PART	2 PCS	23	TABURE SAĞ-SOL YAN	2 AD
24	FOOTSTOOL TOP TABLE	1 PC	24	TABURE ÜST	1 AD
25	FOOTSTOOL BACK PART	1 PC	25	TABURE KAYIT	1 AD

MATERIALS



A	B	C	D	F	G	I
12 PCS	12 PCS	4 PCS	10 PCS	10 PCS	16 PCS	8 PCS
O	R	BP	CE	EC		
2 PCS	2 PCS	9 PCS	1 PCS	12 PCS		

