









ITEM IMAGE							
QTY	BAR TABLE TOP	IRON LEG - 1 PCs.	LEG BASE - 1 PCs.	<b>BOLTS</b> 25x07mm - 04 PCs 42x08mm - 04 PCs	<b>WASHER</b> 20x08 mm - 04 PCs	<b>SPANNER</b> 16-17NO.- 1PCs	<b>SPANNER</b> 14-15NO.- 1PCs


### STEP - 1

lay down the top on the floor.




### STEP - 2

Align the leg with holes at the bottom of the top.(as shown in the figure below.)




### STEP - 3

Tighten the leg with bolts and washers with help of spanner.




### STEP - 4

Align the leg base with holes at the bottom of the leg.  
(as shown in the figure below.)



### STEP - 5

Tighten the leg base with bolts  
help of spanner.



### FINAL STEP

Flip the Bar table now.

